

TOUCH SENSITIVE LOW VOLTAGE DIMMER

WARNING

FOR INDOOR USE ONLY. Regularly check the cord, the power supply and all other parts for damage.

If any part is damaged the product should not be used. Important information! Keep these instructions for future use

CAUTION To reduce the risk of fire, electric shock, or injury to persons: Use only insulated staples or plastic ties to secure cords.

Route and secure cords so that they will not be pinched or damaged

DO NOT TOUCH THE DIMMER IN TWO PLACES AT THE SAME TIME

DO NOT INSTALL THE DIMMER ON CONDUCTIVE MATERIALS

CONSIGNES DE SÉCURITÉ IMPORTANTES. Uniquement pour une utilisation en intérieur. Vérifier régulièrement que le câble, le transformateur et les autres parties ne sont pas endommagés. Si l'une de ces pièces est endommagée, ne pas utiliser le produit. Information importante. Conserver la notice pour toute utilisation ultérieure. Mise en garde La source lumineuse du produit est composée de diodes (LED) qui ne se remplacent pas. Ne jamais démonter le produit, les diodes peuvent causer des blessures aux yeux. Ne jamais immerger dans de l'eau.


ATTENTION! Pour réduire le risque d'incendie, d'électrocution ou de blessure, utiliser uniquement des agrafes isolées ou des liens en plastique pour fixer les câbles.

NE TOUCHEZ PAS LE VARIATEUR À DEUX ENDROITS EN MÊME TEMPS

N'INSTALLEZ PAS LE VARIATEUR SUR DES MATÉRIAUX CONDUCTEURS

Quick-Start Guide :

Thank you for purchasing this touch sensitive dimmer. Before you start please note that the entire housing of the dimmer is touch-sensitive. This means that you can only touch it in one location at a time. Do not try and hold the housing in one hand and tap it with your other hand. It will not work. We recommend that you remove the double-sided adhesive on the back of the dimmer and adhere the dimmer to a fixed surface. Please ensure that the surface you adhere the dimmer to is stable and will not move when the touch dimmer is pressed. Thank you and enjoy your dimmer!



Detailed Instructions :

- 1 - Remove the double sided adhesive on the back of the dimmer and apply to a fixed surface.
- 2 - Plug the female end of the DC power connector tail into the male end of the DC power connector tail on the LED sign
- 3 - Plug the male end of the DC power connector dimmer into the female DC power connector tail on the power supply.
- 4 - Plug in the power supply into an available wall outlet.
- 5 - Tap the housing of the dimmer with one finger to "tap on". The LED should illuminate.
- 6 - Press your finger to the housing of the dimmer and hold. The LED will dim. Remove your finger from the housing of the dimmer once desired brightness level has been achieved. You can press your finger and hold again to increase or decrease the brightness level.
- 7 - Tap again to "top off". The LED will turn off.
- 8 - The touch dimmer has a built-in memory which will recall the last saved brightness level.

Specifications :

• Input Voltage : 12 - 24VDC • Output Voltage : 12 - 24VDC • Max Input Current : 4A • Max Power : 48W for 12VDC and 96W for 24VDC

Wiring Diagram :

